

Design Engineering Inc.

604 Moore Road
Avon Lake, OH 44012



THERMAL TUNING PRODUCTS

Installation Instructions

DEI Versa Shield™

PART NO. 010402

KIT CHECKLIST	
1	Versa-Shield

NOTE

Allow for at least 2" air gap between Versa-Shield and an extreme heat source, failure to do so may damage Versa-Shield.

DIRECTIONS

- 1 - Wrap the item to be protected from heat with the aluminized side out. The reflective aluminized properties offer the protection from the heat source.
- 2 - Attach by pressing the black "loop" material sewn throughout, to the two inch strip of black "hook" material (sewn on end of product) This hook and loop attachment makes for an easy on and quick off.
- 3 - The Versa-Shield can be trimmed or cut with scissors or sharp knife. Relief holes can also be cut into the material to allow for lines etc. For example, when installing Versa-Shield on master cylinders.