



INSTALLATION INSTRUCTIONS

Boom Mat Moldable

KIT CONTENTS:

- #050103 - 24" x 54" (9 sq. ft.) Moldable Noise Barrier
- #050104 - 48" x 54" (18 sq. ft.) Moldable Noise Barrier
- #050105 - BULK 1 Linear ft. x 54"W Moldable Noise Barrier

NOTES:

Boom Mat moldable can be heat molded to fit contours.
Boom Mat moldable seams can also be sealed together with heat.

TOOLS:

Boom Mat blade lock knife (050216) or scissors, heat gun, DEI Hi Temp Spray Adhesive (010490)

SURFACE PREP:

Vacuum installation area to remove all loose debris. Then clean with isopropyl alcohol, soapy water, or a wax/grease remover. Allow sufficient time to dry before installation of Boom Mat products.



INSTRUCTIONS:

1. Making a template will aid in proper and professional installations.

2. Trim Boom Mat Moldable Noise Barrier to desired size using a Boom Mat blade lock knife (DEI part# 050216) or scissors.*

3. After Boom Mat Moldable Noise Barrier is set in proper location, use a heat gun to mold the material to the surface it is being installed on.*

4. After Boom Mat Moldable Noise Barrier has been shaped you may apply DEI Hi-Temp Spray Adhesive (DEI part# 010490) to both the Boom Mat Moldable noise barrier and the surface it is being installed on to secure in place if desired.

*If using a heat gun to mold, trim excess material after molding.

