



INSULATION KIT

NEW

Sprinter™ Van Insulation Kit

If you own a Sprinter Van you know how cold, loud and tinny sounding they can be. Increase comfort with DEI Boom Mat sound damping and insulation kit. Universal kits include enough insulation material to do either a short wheel base or long wheel base Van. Kits also include Boom mat damping material and spray adhesive to complete the installation along with instructions.

- Comfortable interior at any temperature
- Quick & easy installation
- Economical insulating solution
- D-MAT thermal acoustic insulation
- Universal kit

SHORT WHEEL BASE KIT

Part #	Description
050400	Short Wheel Base Kit

Includes 250 sq ft of DEI insulation, enough Boom Mat and Spray adhesive to complete the job.

LONG WHEEL BASE KIT

Part #	Description
050401	Long Wheel Base Kit

Includes 350 sq ft of DEI insulation, enough Boom Mat and Spray adhesive to complete the job.



FOR MORE INFORMATION AND OUR COMPLETE PRODUCT LINE GO TO

DesignEngineering.com    

604 Moore Rd. Avon Lake, Ohio 44012
800-264-9472 • 440-930-7940 • (F) 440-930-7967
sales@designengineering.com