



INSULATION KITS

NEW

Custom Cut Van Insulation Kits

Custom Cut Van insulation kits takes the guess work out of creating a cool, quiet, comfortable interior in your Sprinter, Transit or Promaster Van. CNC custom cut kits include insulation pieces for each specific area of your interior. This reduces installation time, and gives the right solution to properly insulate your van. Boom Mat damping material kits eliminate squeak and rattles, and spray adhesive to complete the installation. Detailed instructions make installation simple.

- Comfortable interior at any temperature
- Quick & easy installation
- Economical insulating solution
- Damping material eliminates, vibrations, squeakes & rattles
- Custom cut 30mm thick D-Mat insulation controls, heat, cold & absorbs noise
- Passes FMVSS-302 Flamability test



EASY INSTALLATION



MODERN MATERIALS



CUSTOM CUT PIECES GREATLY REDUCES INSTALLATION TIME



SPRINTER VAN CUSTOM CUT INSULATION KITS

Model (High Roof Models)	144 WB	144 WB	170 WB	170 WB	170 WB EXT	170 WB EXT
Years	07-18	19-UP	07-18	19-UP	07-18	19-UP
Complete Insulation Kit without Floor	51106	51107	51108	51109	51110	51111
Floor Insulation Kit - Single Rear Wheel	52100	52100	51101	51101	51102	51102
Floor Insulation Kit - Dual Rear Wheel	51103	51103	51104	51104	51105	51105
Complete Damping Kit without Floor	51115	51116	51117	51118	51119	51120
Floor Damping Kit	51112	51112	51113	51113	51114	51114

FORD TRANSIT VAN CUSTOM CUT INSULATION KITS

Model Ford Transit	148 WB High Cube Ext
Years	2023
Complete Insulation Kit without Floor	50454
Damping Material kit	50455

DODGE PROMASTER VAN CUSTOM CUT INSULATION KITS

Model Dodge Promaster	159 WB High Cube Ext
Years	2022
30mm D-Mat Insulation Kit	50456
12mm D-Mat Insulation Kit	50457
Damping Material kit	50458

FOR MORE INFORMATION AND OUR COMPLETE PRODUCT LINE GO TO

DesignEngineering.com    

604 Moore Rd. Avon Lake, Ohio 44012

800-264-9472 • 440-930-7940

sales@designengineering.com