



## INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

**DESCRIPTION:** CryO<sup>2</sup> Intercooler Sprayer

**PART NUMBER:** 080130, 080131, 080134

**KIT CONTENTS:**

Intercooler Spray Bar

1/8" NPT Female to -4AN Adapter

20" Stainless Steel Locking Ties

**NOTE:**

A full tank of CO<sup>2</sup> for connection and testing. Teflon paste or tape is also recommended when connecting fittings to prevent any additional venting.

1. Installation of CryO<sup>2</sup> system and tank required before starting this installation.
2. Attach CryO<sup>2</sup> Intercooler Spray Bar ring to the 1/8" NPT OUT port of the solenoid. Teflon tape/paste is recommended on NPT fittings.
3. Mount the CryO<sup>2</sup> Intercooler Spray Bar to the intercooler using the supplied stainless steel locking ties.

**NOTE:** The CryO<sup>2</sup> Intercooler Spray Bar must be the last component in the CryO<sup>2</sup> system as it serves as a purge that vents the CO<sup>2</sup> on to the intercooler and the solenoid must be positioned prior to the 1st component in the system.

4. Test the system making sure there are no leaks around the fittings. The CryO<sup>2</sup> Intercooler Spray Bar should ice-over within 10 seconds. If ice immediately forms over any fittings or lines retighten any connection and recheck for further leaks .