



## INSTALLATION INSTRUCTIONS

Thank you for purchasing genuine Design Engineering, Inc. products. Be sure to always wear the proper safety equipment when installing any DEI product. Design Engineering Inc. WILL NOT BE HELD LIABLE FOR IMPROPER INSTALLATION OR USE OF THIS PRODUCT. Please follow all instructions provided. If you are unsure of any installation procedure, please contact a certified technician.

**DESCRIPTION:** Titanium Exhaust Wrap 10095

**KIT CONTENTS:**

- 2 rolls 2"x 50ft Titanium Wrap
- Stainless Steel Locking Ties
- Locking Tie Tool

**TOOLS NEEDED:**

- Scissors
- 1/4" drive

**SAFETY:**

- Safety glasses
- Gloves
- Mask



**AVOID SKIN CONTACT WITH FIBERS**  
**MAY CAUSE TEMPORARY IRRITATION - PROTECTIVE EYE WEAR AND GLOVES**  
**RECOMMENDED - AVOID INHALATION (OF LOOSE FIBERS)**



**NOTE:** Utilize a 1/4" overlap when wrapping pipes.

**STEP 1:** Measure primary pipes (header) from the exhaust to the collector to the header flange. Use the chart below to determine the length needed to cut for each section of pipe.

**HINT:** Wrapping a pipe takes time and concentration. The tighter the wrapping, the better the hold and less chance of a loose or irregular fit. For additional assistance consider anchoring one end of the wrap as it will aid in a much tighter wrap for increased heat isolation.

**STEP 2:** Begin wrapping starting at the collector. Wrap tightly and secure with a DEI Stainless Steel Locking Tie or clamp. Testing has shown using a 1/4" overlap produces the best results without adversely affecting the metal.

**STEP 3:** When primary tubes are close together, wrap the pipes to the point of closeness or contact and secure at the end. On the final pipe, begin wrapping where primary tubes meet. Wrap all the unwrapped pipes simultaneously using the same 1/4" overlap.

**STEP 4:** Proceed to wrap up to the exhaust flange and secure with DEI Locking Ties or clamps



**Titanium  
Wrap Install  
Video**

**Scan Code to Watch  
Video Installation**

**Please scan below to watch full  
how-to installation video and tips and tricks  
to get a professional result**